


Supplementary instructions

Peristaltic metering pump DULCO flex Control - DFYa with PROFIBUS®



These operating instructions are only valid when read in conjunction with the "Operating instructions for the peristaltic metering pump DULCO flex Control - DfYa"!

The operator is liable for any damage caused by installation and operating errors!

**Please carefully read these operating instructions before use. · Do not discard.
The operator shall be liable for any damage caused by installation or operating errors.
The latest version of the operating instructions are available on our homepage.**

Table of contents

1	Requirements	3
2	Setting up the pump	4
	2.1 General.....	4
	2.2 Setting up the slave address.....	4
	2.3 Switching PROFIBUS® to active / inactive.....	4
3	Special features in active PROFIBUS® mode	5
	3.1 General.....	5
	3.2 Displays.....	5
	3.3 LEDs on the PROFIBUS® module.....	5
4	Installation	6
5	Operation	8
	5.1 General.....	8
	5.2 GSD file.....	8
	5.3 Description of the data objects.....	8
	5.4 Cyclic data transmission.....	11
	5.4.1 Overview of the data objects.....	11
	5.4.2 Configuration.....	14
	5.5 Acyclic data transmission.....	16
	5.6 Extended diagnostics.....	18

1 Requirements

The pump can be enhanced with PROFIBUS® functionality by means of a plug-in module. To do this, insert the plug-in module into the front of the pump (similar to a relay module). The operating menu then displays the menu item 'Fieldbus' and the status bar shows the PROFIBUS® symbol.



The pump must have the software version V04.03.02.00 or higher for the PROFIBUS® module to work. If it is not working, the LED on the PROFIBUS® module slowly flashes red and green.

2 Setting up the pump

2.1 General


The pump with the plugged-in PROFIBUS® module is set up in the same way as the standard pump, with the addition of the bus functionality.





The pump interrupts the set-up process in the event of pauses longer than 60 s.

2.2 Setting up the slave address

The address is pre-set to “125”. There is no need to manually set up the slave address if a master in the PROFIBUS® segment assigns the slave addresses.


1. ➤ Press the  [Menu] key.
2. ➤ Turn the [Clickwheel] to 'Fieldbus' and press the [Clickwheel].
3. ➤ Turn the [Clickwheel] to 'BUS Address' and press the [Clickwheel].

Always enter the PROFIBUS® address as 3 digits (addresses between “002” and “125”):

1. ➤ Set the 1st digit using the [Clickwheel] and press the  [Priming] key.
 - ⇒ The 2nd digit of the address is highlighted.
2. ➤ Set the 2nd digit using the [Clickwheel] and press the  [Priming] key.
 - ⇒ The 3rd digit of the address is highlighted.
3. ➤ Set the 3rd digit using the [Clickwheel] and press the [Clickwheel].

2.3 Switching PROFIBUS® to active / inactive

'Fieldbus' must be set to 'Active' in the operating menu for the pump to be controlled using the PROFIBUS®:

1. ➤ Press the  [Menu] key.
2. ➤ Turn the [Clickwheel] to 'Bus active' and press the [Clickwheel].
3. ➤ Turn the [Clickwheel] to 'Active' or 'Inactive' and press the [Clickwheel]. You're done!

All external inputs, such as level monitoring and external control (pause, contact input, analogue input), will continue to function while the PROFIBUS® is 'active'. They result in the reactions that would be expected with the pump without the PROFIBUS® module being plugged in - refer to "Operating instructions for the peristaltic pump DULCO flex Control - DFYa". The pump transmits relevant information via the PROFIBUS® to the master (PLC, PC etc.).

If the PROFIBUS® is set to 'inactive', the settings for the operating mode previously selected are reloaded.

If the pump is switched to another operating mode, it stops and can only be restarted using the [Stop/Start] key.

3 Special features in active PROFIBUS® mode

3.1 General



The pump cannot be manually set or programmed in PROFIBUS® mode! To do this, set the PROFIBUS® to 'Inactive'.

- The [Clickwheel] can be used to switch between the continuous displays at any time, as in the other operating modes. This does not affect the operation of the pump.
- The settings from other operating modes are carried over when switching over to PROFIBUS® operation. **However, settings made using the PROFIBUS® are not saved!** They only apply as long as the pump is connected to the PROFIBUS®. Only the total number of revolutions and the total number of litres continue to be counted and saved.
- If the pump is switched to PROFIBUS® mode, it stops and can only be restarted using the PROFIBUS®.

3.2 Displays


Operating display

There are additional identifiers in the operating display when PROFIBUS® mode is running.



The commonly used identifiers can be found in the "Controls" chapter in the "Operating instructions for the peristaltic metering pump DULCO flex Control - DFYa".

Status display

 Stop PROFIBUS®: the pump has been stopped using PROFIBUS®. The master has sent the pump a corresponding telegram.

Main display

➡ Connection error: If the pump loses its connection to the PROFIBUS® (for instance as soon as the PROFIBUS® is stopped), an error message with the ➡ symbol appears on the main display.

3.3 LEDs on the PROFIBUS® module

LEDs	Cause
Flashing red and green at a slow rhythm	Connection between the PROFIBUS® module and pump has been disrupted; the hardware or software version of the pump may not be suitable for PROFIBUS®
Lit red	No connection to the PROFIBUS®
Lit green	Pump in cyclic operation

4 Installation

Bus installation

All devices that are members of the bus system must be connected in a line. There are up to 32 possible positions (master, slaves, repeaters).

At both the beginning and end of the cable, the bus must be terminated with a terminating resistance.

Plugs and cables

For the PROFIBUS® cable, use a screened, twisted-pair cable in conformity with EN 50170 (cable type A).



Use of shielding which is earthed at one end prevents low-frequency ground loops. Shielding earthed at one end has no effect in combating HF magnetic pick-up. Shielding earthed at both ends as well as twisted conductors work to counter magnetic HF pick-up, but have no effect against electrical HF pick-up.

For PROFIBUS®, it is recommended to establish a bilateral, low-inductance (i.e., large area and low-impedance) connection with the protective earth.

The overall length of the bus cabling without repeaters varies according to the desired data transmission rate:

Tab. 1: Data transmission rate and length of the bus cabling

Data transmission rate	Maximum length of bus cabling
kBit/s	m
1500	200
500	400
187.5	1000
93.75	1200
19.2	1200
9.6	1200

The PROFIBUS® module has a M12 industry socket for connection to the PROFIBUS® cable. The pin configuration complies with the PROFIBUS® standard - see below - which means that commercially available bus plugs may be used. Please note that cable connections made with these plugs generally only meet the requirements for protection against contact and moisture according to IP 20!

Note for achieving IP 65 degree of protection

An installation compliant with the protection against contact and moisture according to IP 65 is possible, since the M12 industry socket of the PROFIBUS® module allows this. However, in this case the PROFIBUS® cable must also be fitted with M12 industry plugs in conformity with IP 65.


In order to achieve the IP 65 degree of protection for the PROFIBUS® cable installation, special Y-adapters or terminating adapters must be installed (e.g. - see below).



CAUTION!

- Degree of protection IP 65 applies only to a plug/socket combination that has been screwed together!
- In ambient conditions requiring protection against contact and moisture according to IP 65, cables with moulded M12 industry plugs must be used (e.g., see below).
- Degree of protection IP 65 applies only to an unwired pump (with PROFIBUS® module) if an IP 65-capable cover is placed over the M12 industry socket! The cover included in the delivery does not guarantee chemical resistance.


Socket on the PROFIBUS® module (M12)



- 1 5 V
- 2 A conductor (green)
- 3 GND
- 4 B conductor (red)
- 5 Shielding


Y-adapter (order no. 1040956)

The Y-adapter connects to the pump using a moulded M12 plug. The ends are provided with an M12 plug and an M12 socket. The Y-adapter complies with the requirements for protection against contact and moisture according to IP 65.



PROFIBUS® termination, complete (order no. 1040955)

If the pump is the last bus device connected to the PROFIBUS® cable, it must be connected completely as a termination using the PROFIBUS® termination - see EN 50170. The PROFIBUS® termination, complete, complies with the requirements for protection against contact and moisture according to IP 65. (It consists of a Y-plug and terminating resistance.)



5 Operation

5.1 General

The plugged-in PROFIBUS® module make the PROFIBUS® pump a unit with slave functionality in compliance with DP-V1. This means that the usage data is transmitted both cyclically and acyclically.

5.2 GSD file

Use the GSD file to configure the master. It describes all features of the pump in PROFIBUS® mode (keywords, diagnostics, modules, slots). The GSD file can be downloaded from the PROFIBUS® website and from the ProMinent website. The file name is unique: DFYA1180.GSD

5.3 Description of the data objects

Description of the data objects



The initial parameters must be transmitted from the master so that the pump can engage in cyclic data transmission. Only standard parametrisation is needed for this – there are no application-specific parameters.



Please note: Data is stored according to the “Big-Endian” principle! This means that the byte with the highest-value bits is stored first at the memory location with the lowest storage address. Refer to the section below for an example based on “Status”:

The pump status is stored as UINT32 type at the offset addresses +0 to +3. Bytes are stored in this sequence:

Name	Type	Offset	Byte	Bits
Status	UINT32	+0	0	24 ... 31
		+1	1	16 ... 23
		+2	2	8 ... 15
		+3	3	0 ... 7

All the data objects that can be cyclically transmitted are described below.

Tab. 2: All data objects

Name	No.	Type	Description		
Unit identifier	0	UINT32	Byte 0+1	= 0x1180	Identification number
			Byte 2	= 0x50	ProMinent identifier for pump product group
			Byte 3	= 8	“DULCO flex Control” pump family
Status	1	UINT32	bit	Name	Function
			0	Motor	0 – Motor idle 1 – Motor running

Name	No.	Type	Description			
			1		-	-
			2	Mode	00 – halt	03 – contact
			3		01 – manual	04 - analog
			4		02 – batch	
			5	Error	There are errors - see “Errors”	
			6	Warnings	There are warnings - see “Warnings”	
			7	Manual stop	Pump has been stopped manually	
			8	Stop	Pump has stopped	
			9	Priming	Pump is in priming mode (higher-level function)	
			10	Auxiliary	Pump is in auxiliary mode (higher-level function)	
			11	Pause	Pump has been switched to pause (higher-level function)	
			12	Module	Fieldbus mode active	
			13	Hose change	Hose is being changed	
			14	Batch Mem.	Batch memory is activated	
			15	Calibrated	Pump is calibrated	
			16	Relay 1	Relay 1 physically exists	
			17	Relay 2	Relay 2 physically exists	
			18	AnalogOut	Module physically exists	
			19	Hose rupture	Hose rupture sensor is installed	
			20	Actual direction of rotation	0 = clockwise 1 = counter-clockwise The user should stop the pump and wait for release to change the direction of rotation(Bit #21 in the status). Only than can the direction of rotation be reversed.	
			21	Direction of rotation	Release for change of direction of rotation	
			22	-	-	
			24	-	-	
			27	-	-	
Start-Stop	2	BYTE	Corresponds to Start-Stop switch; if Start-Stop = 0, then the pump is stopped.			
Reset	3	BYTE	If the “Reset” value is switched from 1 to 0, the internal pump memory is deleted (e.g. with batch metering) and - as far as possible - existing errors are cleared.			
Mode	4, 5	BYTE	Value	Name	Description	
			0	Halt	Pump is ready but not metering.	
			1	Manual	Pump is metering continuously at the set frequency.	

Operation

Name	No.	Type	Description		
			2	Batch	When triggered, the pump meters the number of revolutions set in batch pre-selection.
			3	Contact	Pump meters the number of revolutions calculated from the product of "Number of triggers * External factor".
			4	Analog	Pump meters according to the analogue signal and the 'Analog' mode set on the pump.
Dos. capacity	6, 7	UINT16	Capacity set in litres / hour ("Minimum" .. "Maximum capacity").		
Actual capacity	8	UINT16	Actual capacity in litres / hour (0.. "Maximum capacity").		
Maximum capacity	9	UINT16	Maximum dosing rate in litres / hour		
Batch pre-selection	10, 11	UINT32	Number of half revolutions in batch mode per trigger. (12 ... Maximum = 999.999 litres / trigger).		
Batch start	12	BYTE	If the value changes from 1 to 0, batch metering is activated in batch mode. Batches can also be activated via the contact input.		
Batch memory	13	BYTE	<p>If the batch memory is activated and a new batch is triggered during batch metering already in progress, then the remaining revolutions are increased by the number of the new batch.</p> <p>If the memory is not activated, the remaining revolutions of the batch not yet processed are cleared and the new batch is processed.</p>		
Remaining revolutions	14	UINT32	The remaining revolutions still to be processed with batch metering		
External factor	15, 16	UINT16	Factor by which the incoming pulses are multiplied. The factor is given as a hundredth. Value range is 2...19998 - the factor is then 0.01...99.99 revolutions.		
External memory	17	BYTE	As with batch metering, again here totalling is undertaken with high factors or the remaining revolutions are cleared.		
Direction of rotation	19	UINT16	Target direction of rotation 0 = clockwise and 1 = counter-clockwise		
Hose service life	20	UINT32	Hose service life - revolutions since the last hose change		
Error	21	UINT16	bit	Name	Function
			0	Minimum	Metering liquid level too low
			1	Batch	Too many revolutions > 100000
			2	Analog < 4 mA	Analogue current is less than 4 mA
			3	Analog > 23 mA	Analogue current is greater than 23 mA
			4	Temperature fault	Temperature too high
			5	Hose rupture	Metering hose damaged
			6	-	-
			7	-	-
			8	-	-
			9	-	-
			11	-	-

Name	No.	Type	Description		
			13	Bus error	Bus error reported by the module
			14	System error	System components faulty - see LCD screen
			15	Module error	Error in module handling
Warnings	22	UINT16	bit	Name	Function
			0	Minimum	Metering liquid level too low
			1	Calibration	-
			2	-	-
			3	-	-
			4	-	-
			5	-	-
			6	-	-
			7	-	-
			8	-	-
Revolutions counter	23	UINT32	Counts the number of revolutions since the last reset		
Reset revolutions counter	24	UINT8	If the value changes from 1 to 0, the revolutions counter is reset		
Volume counter	25	FLOAT32	Volume counter		
Litres per revolution	26	FLOAT32	Litres per revolution		
Clear volume counter	27	UINT8	If the value changes from 1 to 0, the volume counter is cleared		
Identity code	28	STRING32	Pump identity code (pump specification)		
Serial number	29	STRING16	Pump serial number		
Name	30	STRING32	Pump name, freely selectable (max. 32 characters)		
Installation site	31	STRING32	Installation site, freely selectable. (max. 32 characters)		

5.4 Cyclic data transmission

DP-V0 describes the cyclic data transmission in the PROFIBUS®.

5.4.1 Overview of the data objects

The data objects are summarised into modules and their configuration identifier - see following table. The configuration identifier enables modules to be excluded from cyclic data transmission during configuration to avoid unnecessarily burdening the cyclic data transmission.

Tab. 3: Modular construction

Module no.	Output	Length	Input	Length	Module name	Configuration identifier (hex)
1	-	-	Status	4 bytes	Status	40.83
2	Start-Stop Reset	1 bytes 1 bytes	-	-	Control	80.81
3	Mode	1 bytes	Mode	1 bytes	Operating mode	C0,80,80
4	Dos. capacity	2 bytes	Dos. capacity Actual capacity	2 bytes 2 bytes	Capacity	C0,81,83
5	-	-	Maximum capacity	2 bytes	Maximum capacity	40.81
6	Batch pre-selection Batch start Batch memory	4 bytes 1 bytes 1 bytes	Batch pre-selection	4 bytes	Batching	C0,85,83
7	-	-	Remaining revolutions	4 bytes	Remaining revolutions	40.83
8	External factor External memory	2 bytes 1 bytes	External factor	2 bytes	Transmission multiplier	C0,82,81
9	-	-	-	-	-	40.80
10	Direction of rotation*	2 bytes	-	-	Direction of rotation	80.80
11	Hose service life	-	Hose service life	4 bytes	Tube lifespan	40.83
12	-	-	Error Warnings	2 bytes 2 bytes	Error warning	40.83
13	Clear revolutions counter	1 bytes	Revolutions counter	4 bytes	Revolution number	C0,80,83
14	Clear volume counter	1 bytes	Volume counter Litres per revolution	4 bytes 4 bytes	Quantity	C0,80,87

* only change once the pump has stopped!

Tab. 4: Pump data (output data)

Offset	Value	Type	Name	Range	Module name	Module no.
+0	-	BYTE	Start-Stop	0.1	Control	2
+1	-	BYTE	Reset	0.1 ↓	-	
+2	-	BYTE	Mode	see ☞ Tab. 3 'Modular construction' on page 12	Operating mode	3
+3	high	UINT16	Dos. capacity	0..max. Freq.	capacity	4
+4	low					

Offset	Value	Type	Name	Range	Module name	Module no.
+5	high	UINT32	Batch pre-selection	1..99999	Batching	6
+6	↓					
+7	low					
+8						
+9	-	BYTE	Batch start	0.1 ↓	-	
+10	-	BYTE	Batch memory	0.1	-	
+11	high	UINT16	External factor	0..9999	Transmission multiplier	8
+12	low					
+13	-	BYTE	External memory	0.1	-	
+14	-	BYTE	-	0.1	-	10
+15	-	BYTE	Clear revolutions counter	0.1 ↓	Revolution number	13
+16	-	BYTE	Clear volume counter	0.1 ↓	Quantity	14

Tab. 5: Pump data (input data)

Offset	Value	Type	Name	Range	Module name	Module no.
+0	high	UINT32	Status	see ↪ Tab. 4 'Pump data (output data)' on page 12	Status	1
+1	↓					
+2	low					
+3						
+4	-	BYTE	Mode	see ↪ Tab. 3 'Modular construction' on page 12@ @	Operating mode	3
+5	high	UINT16	Dos. capacity	0..max. Freq.	capacity	4
+6	low					
+7	high	UINT16	Actual capacity	0..max. Freq.		
+8	low					
+9	high	UINT16	Maximum capacity	e.g. 410 l/h ↓	Maximum capacity	5
+10	low					
+11	high	UINT32	Batch pre-selection	12..maximum half revolutions for a maximum metering volume of 999.999 litres / trigger	Batching	6
+12	↓					
+13	low					
+14						
+15	high	UINT32	Remaining revolutions	1..99999	Remaining revolutions	7
+16	↓					
+17	low					
+18						
+19	high	UINT16	External factor	2..19998	Transmission multiplier	8
+20	low					

Offset	Value	Type	Name	Range	Module name	Module no.
+21	-	BYTE	-	-↓	-	9
+26	high	UINT16	Error	see ↗ <i>Further information on page 8</i>	Error warning	12
+27	low					
+28	high	UINT16	Warnings	see ↗ <i>Further information on page 8</i>		
+29	low					
+30	high	UINT32	Revolutions counter	0..(2 ³²)-1	Revolution number	13
+31	↓					
+32	low					
+33						
+34	high	FLOAT	Volume counter	... (litres)	Quantity	14
+35	↓					
+36	low					
+37						
+38	high	FLOAT	ml per revolution	... (litres)		
+39	↓					
+40	low					
+41						

5.4.2 Configuration

It is possible to select on the master which modules are to be involved in cyclic data transmission. Modules and slots always relate to each other. Empty spaces (empty modules) therefore have to be configured for modules to be excluded.

The target configuration is defined in the form of identifiers. The identifier is stated in the last column in for every defined module.

The identifiers of the modules have to be listed successively in ascending order. If the data of a module is not to be involved in cyclic data transmission, then an empty module must be configured at this point.

Suggested configurations

Tab. 6: Configuration for the transmission of all cyclic modules (42 byte input, 17 byte output)

Module 1	Module 2	Module 3	Module 4	Module 5	Module 6	Module 7	Module 8
40, 83	80, 81	C0, 80, 80	C0, 81, 83	80, 81	C0, 85, 83	40, 83	C0, 82, 81

Module 9	Module 10	Module 11	Module 12	Module 13	Module 14		
40, 83	80, 80	80, 80	40, 83	C0, 80, 83	C0, 80, 87		

The following table shows an example of a target configuration in which modules 8, 10, 11 and 14 are excluded from the cyclic data transmission.

INFORMATION

The data objects can still be reached acyclically.

Tab. 7: Target configuration

Module 1	Module 2	Module 3	Module 4	Module 5	Module 6	Module 7	Module 8
40 83	80 81	C0 80 80	C0 81 83	80 81	C0 85 83	40 83	0

Module 9	Module 10	Module 11	Module 12	Module 13	Module 14		
40 80	0	0	40 83	C0 80 83	0		

The pump checks whether the target configuration corresponds to the actual configuration. If this is not the case, the pump reacts and emits a configuration error in the standard diagnostics.

The options for creating the identifier formats must be limited and the following rules observed for the target configuration to function.

- Always use the special identifier format for coding.
- Always use the byte structure as the format.
- Do not state any manufacturer-specific data (e.g. data types).
- Modules must always be replaced with empty modules to remove them from cyclic data transmission.

The offset addresses of the transmitted data objects will shift by excluding individual modules from the cyclic data transmission - see and :

Tab. 8: Pump data (reduced output data)

Offset	Value	Type	Name	Range	Module name	Module no.
+0	-	BYTE	Start-Stop	0.1	Control	2
+1	-	BYTE	Reset	0.1 ↓		
+2	-	BYTE	Mode	see	Operating mode	3
+3	high	UINT16	Dos. capacity	0..max. Freq.	capacity	4
+4	low					
+5	high	UINT32	Batch pre-selection	12..maximum half revolutions for a maximum metering volume of 999.999 litres / trigger	Batching	6
+6	↓					
+7	low					
+8						
+9	-	BYTE	Batch start	0.1 ↓		

Offset	Value	Type	Name	Range	Module name	Module no.
+10	-	BYTE	Batch memory	0.1		
+11	-	BYTE	Clear revolutions counter	0.1 ↓	Revolution number	13

Tab. 9: Pump data (reduced input data)

Offset	Value	Type	Name	Range	Module name	Module no.
+0	high	UINT32	Status	see	Status	1
+1	↓					
+2	low					
+3						
+4	-	BYTE	Mode	see	Operating mode	3
+5	high	UINT16	Dos. capacity	0..max. Freq.	capacity	4
+6	low					
+7	high	UINT16	Actual capacity	0..max. Freq.		
+8	low					
+9	high	UINT16	Maximum capacity	e.g. 410 l/h ↓ ↓	Maximum capacity	5
+10	low					
+11	high	UINT32	Batch pre-selection	12..maximum half revolutions for a maximum metering volume of 999.999 litres / trigger	Batching	6
+12	↓					
+13	low					
+14						
+15	high	UINT32	Remaining revolutions	1..99999	Remaining revolutions	7
+16	↓					
+17	low					
+18						
+19	-	BYTE	-	- ↓	-	9
+20	high	UINT16	Error	see	Error warning	12
+21	low					
+22	high	UINT16	Warnings	see		
+23	low					
+24	high	UINT32	Revolutions counter	0..(2 ³²)-1	Revolution number	13
+25	↓					
+26	low					
+27						

5.5 Acyclic data transmission

(from DP-V1)

The acyclically transmitted data is addressed via slot and index. All data summarised under one slot can then be addressed individually via the index and be transmitted acyclically.



*Slots are identical to the **modules** of the cyclical transmission.*

Tab. 10: Slots of the acyclic data objects

No.	Slot	Index	Data object	Type	Length	Channel	Channel	read / write
0	Slot 0	1	Unit identifier	UINT32	4 bytes	MS1	MS2	read
1	Slot 1	1	Status	UINT32	4 bytes	MS1	MS2	read
2	Slot 2	1	Start-Stop	BYTE	1 bytes	MS1	MS2	write
3		2	Reset	BYTE	1 bytes	MS1	MS2	write
4	Slot 3	1	Mode	BYTE	1 bytes	MS1	MS2	write
5		2	Mode	BYTE	1 bytes	MS1	MS2	read
6	Slot 4	1	Dos. capacity	UINT16	2 bytes	MS1	MS2	write
7		2	Dos. capacity	UINT16	2 bytes	MS1	MS2	read
8		3	Actual capacity	UINT16	2 bytes	MS1	MS2	read
9	Slot 5	1	Maximum capacity	WORD	2 bytes	MS1	MS2	read
10	Slot 6	1	Batch pre-selection	UINT32	4 bytes	MS1	MS2	write
11		2	Batch pre-selection	UINT32	4 bytes	MS1	MS2	read
12		3	Batch start	BYTE	1 bytes	MS1	MS2	write
13		4	Batch memory	BYTE	1 bytes	MS1	MS2	write
14	Slot 7	1	Remaining revolutions	UINT32	4 bytes	MS1	MS2	read
15	Slot 8	1	External factor	UINT16	2 bytes	MS1	MS2	write
16		2	External factor	UINT16	2 bytes	MS1	MS2	read
17		4	External factor	BYTE	1 bytes	MS1	MS2	write
18	Slot 9	1	-	BYTE	1 bytes	MS1	MS2	read
19	Slot 10	1	-	BYTE	1 bytes	MS1	MS2	write
21	Slot 12	1	Error	UINT16	2 bytes	MS1	MS2	read
22		2	Warnings	UINT16	2 bytes	MS1	MS2	read
23	Slot 13	1	Revolutions counter	UINT32	4 bytes	MS1	MS2	read
24		3	Clear revolutions counter	BYTE	1 bytes	MS1	MS2	write
25	Slot 14	1	Volume counter	FLOAT	4 bytes	MS1	MS2	read
26		2	Litres per revolution	FLOAT	4 bytes	MS1	MS2	read
27		3	Clear volume counter	BYTE	1 bytes	MS1	MS2	write
28	Slot 15	1	Identity code	STRING	32 bytes	MS1	MS2	read
29		2	Serial number	STRING	16 bytes	MS1	MS2	read
30		3	Device names	STRING	32 bytes	MS1	MS2	read / write
31		4	Installation place	STRING	16 bytes	MS1	MS2	read / write

5.6 Extended diagnostics

(from the 7th byte)

The pump uses the mechanism of the extended PROFIBUS® diagnostics to report error statuses to the master. The extended diagnostics can be found in the diagnostics telegram. The extended diagnostics include the device-related “Alarm_Type (48)” and the “Diagnostic_User_Data”.

Tab. 11: Construction of the extended PROFIBUS® diagnostics telegram

Header_Byte	Alarm_Type	Slot_Number	Alarm_Specifier	Diagnostic_User_Data
Bit 1-6: Length of the status message, including Header_Byte	48	1	1	see Table ↪ Tab. 12 'Diagnostic_User_Data' on page 18
Bit 7-8: 0				

Diagnostic_User_Data consists of a minimum of one group of 3 bytes with error information. Diagnostic_User_Data consists of a maximum of 19 groups. The error information of a group is coded as follows:

Tab. 12: Diagnostic_User_Data

Service no. (1st byte) (2nd byte)	Error type Type of data access (3rd byte)
No. – see Table ↪ Chapter 5 'Operation' on page 8	
0x30	OK
0x31	Date outside of limits
0x32	Date protected
0x34	Option not installed
0x35	Service not defined
0x36	Value cannot be changed
0x37	Update completed
0x55	Communication error
0xD3	Write access
0xE5	Read access

ProMinent GmbH
Im Schuhmachergewann 5-11
69123 Heidelberg
Germany
Telephone: +49 6221 842-0
Fax: +49 6221 842-419
Email: info@prominent.com
Internet: www.prominent.com

999768, 1, en_GB