


EXPLODED VIEW



350 PVT with diaphragm failure (basic)

- 1 Safety diaphragm
- 2 Backplate
- 3 Secondary containment diaphragm and hub
- 4 Leak detection spacer
- 5 Leak detection pressure switch assembly
 - a Pressure switch
 - b Spacer
 - c Diaphragm
 - d Body
 - e Gasket
- 6 Diaphragm
- 7 Pump head

#SIG6PVT-1/97NA