

# Installation Instructions

MODEL: \_\_\_\_\_ USB s/# \_\_\_\_\_  
Data Plan: \_\_\_\_\_ Router s/# \_\_\_\_\_

This modemMillie™ cellular internet modem comes pre-assembled and pre-programmed out of the box ready for plug & play with your Prominent water treatment controller.

**Before installation:** Complete and email/fax the Activation Order (located inside the box), and make sure that you have received confirmation that the device has been activated.

## To install:

1. Check the controller current IP setup. If you do not have any special requirement and current setup is different than the default values listed below for your controller, adjust controller IP values to the default values.

### Multiflex / Aegis / DCM

### MicroFlex / Slimflex

#### Default IP set-up used to preprogram modemMillie

IP address	10.10.6.106	10.10.6.101 (101 SlimFlex)
remote/local port	8585 / 80	8484 / 80
Remote/localport#2	2385 / 23	-- / --
Submask	255.255.255.0	255.255.255.0
Gateway	10.10.6.19	10.10.6.19

2. Plug in Ethernet cable to the controller Ethernet port.

3. Power up modem.

➔ Then, if you would like us to verify connection to modem and the controller , give us a call at 1-608-230-6182.