

# Technical Information:

**Date:** June 21, 2004  
**Subject:** Connect ProMinent Level Switch to Aquatrac MultiFLEX Controller  
**Product:** Aquatrac  
**Page:** 1 of 1

The process of connecting a ProMinent Level Switch to a MultiFLEX Controller is as follows:

1. Install the level switch into a chemical drum as shown in the figure and run the wires into the Aquatrac Controller.
2. Connect 1 wire to input "O" or any other unused digital inputs and the other wire into  $\perp$ .  
 (Note if a 3-stage switch is being used the common wire must connect to  $\perp$  and the remaining 2 connect to separate Digital Inputs).
3. Confirm that the digital input being configured is specified as a "Contact Set" via the keypad or Browser interface.

**M7 Module  
Sensor Locations**

