

Operating Instructions


DULCOMETER® D1C

Part 2: Adjustment and Operation,
Measured variable peracetic acid (PAA)

D1C2-PES-001-GB



Type D



Type W

D1C A

Please enter the identity code of your device here.

**Please completely read through operating instructions! · Do not discard!
The warranty shall be invalidated by damage caused by operating errors!**

1 Device Identification / Identity Code

D1C A	DULCOMETER® Controller Series D1C / Version A														
	Type of mounting														
D	Control panel installation 96 x 96 mm														
W	Wall mounting														
	Operating voltage														
0	230 V 50/60 Hz														
1	115 V 50/60 Hz														
2	200 V 50/60 Hz (only with control panel installation)														
3	100 V 50/60 Hz (only with control panel installation)														
4	24 V AC/DC														
	Measured variable														
A	Peracetic Acide														
	Connection of measured variable														
1	Terminal, standard signal 0/4-20 mA														
7	Terminal, standard signal 0/4-20 mA for PAA 1-mA-200 ppm, PAA 1-mA-2000 ppm														
	Correction variable														
4	manual temperature input														
	Feed forward control														
0	None														
1	via standard signal 0/4-20 mA														
2	via frequency 0-500 Hz														
3	via frequency 0-10 Hz														
	Control input														
0	None														
1	Pause														
	Signal output														
0	None														
1	standard signal 0/4-20 mA measured value														
2	standard signal 0/4-20 mA control variable														
3	standard signal 0/4-20 mA correction variable														
4	2 standard signal 0/4-20 mA outputs, free programmable														
	Power control														
G	Alarm and 2 limit value relays														
M	Alarm and 2 solenoid valve relays														
R	Alarm relay and servomotor with feedback														
	Pump control														
0	None														
2	Two pumps														
	Control characteristic														
0	None														
1	Proportional control														
2	PID control														
	Log output														
0	None														
	Language														
D	German														
E	English														
F	French														
I	Italian														
N	Dutch														
S	Spanish														
B	Portuguese														
G	Czech														
J	Japanese														

D1C A _ _ _ _ _ _ _ _ _ _

Please enter the identity code of your device here!

	Page
1 Device Identification / Identity Code	2
2 General User Information	3
3 Device Overview / Controls	4
4 Functional Description	5
5 Display Symbols	6
6 Operation	7
7 Restricted Operating Menu	8
Overview	8
Description	9
8 Complete Operating Menu	12
Overview	12
Description	13
9 EC Declaration of Conformity	25
10 Faults / Remarks / Troubleshooting	26

General User Information


These operating instructions describe the technical data and function of the series DULCOMETER® D1C controller, provide detailed safety information and are divided into clear steps.



IMPORTANT

- *Please observe the parts of these operating instructions applicable to your particular version! This is indicated in the Section “Device Identification / Identity Code”!*
- *Correct measuring and dosing is only possible in the case of impeccable operation of the probe. The probe has to be calibrated / checked regularly!*

3 **Device Overview / Controls**



	CHANGE Button To change over within a menu level and to change from one variable to another within a menu point.
	START/STOP Button Start/stop of control and metering function.
	ENTER Button To accept, confirm or save a displayed value or status. For alarm acknowledgement.

	UP Button To increase a displayed numerical value and to change variables (flashing display).
	BRANCH BACK Button Back to permanent display or to start of relevant setting menu.
	DOWN Button To decrease a displayed numerical value and to change variables (flashing display).

4 Functional Description

NOTE

Please refer to the description of the complete operating menu in Section 8 for a detailed description of the individual characteristics of the DULCOMETER® D1C controller!

4.1 Operating Menu

The D1C controller permits settings to be made in two different menus. All values are preset and can be changed in the **complete operating menu**.

The controller is delivered with a **restricted operating menu** so that the D1C controller can be used effectively in many applications from the very onset. If adaptations prove to be necessary, all relevant parameters can then be accessed by switching over to the complete operating menu (see "General settings").

4.2 Access Code

Access to the setting menu can be prevented by setting up an access code. The D1C controller is supplied with the access code 5000 which permits free access to the setting menu. The calibration menu remains freely accessible even when access to the setting menu is blocked by the code.

4.3 Control

The D1C can operate as a proportional controller or as a PID controller - dependent on the device version (see identity code) and the setting.

The controlled variable is recalculated once a second. Control procedures which require rapid correction of setpoint deviations (less than approx. 30 seconds) cannot be processed with this controller. The cycle times must be taken into consideration when activating solenoid valves (pulse length) in the same way as their running times when activating servomotors (3-point).

Via the control input pause, the control function (selection of controlled variable) can be switched off. The calculation of the controlled variable starts again after cessation of "pause".

4.4 Feed Forward Control

The D1C controller can process a signal of a feed forward control. Depending on the device version (see identity code) and the setting, this signal can be obtained in any form of a 0–20 mA or 4–20 mA signal or as a digital contact signal with the maximum frequencies 10 Hz or 500 Hz.

During start-up, the zero point has to be checked. The multiplicative feed forward control is not designed for switching off permanently the actuating variable (signal ≈ 0).

This signal can be used, for example, for flow-proportional metering (multiplicative effect) or feed forward-dependent basic load metering (additive effect). The result of control variable calculation from the proportional or PID control is multiplied by or added to the feed forward signal. A multiplicative feed forward variable at the level of the set rated value carries over the calculated control variable unchanged into the controlled variable:

$$\text{Controlled variable} = \text{Feed forward variable} / \text{rated value} \times \text{calculated control variable}$$

An additive feed forward variable at the level of the rated value results in maximum controlled variable:

$$\text{Controlled variable (max. 100 \%)} = \text{Feed forward variable} / \text{rated value} \times \text{max. controlled variable} + \text{calculated control variable}$$























4.5 Error Messages

Error messages and information are indicated on the bottom line in the permanent display 1. Errors to be acknowledged (acknowledgement switches off the alarm relay) are indicated by the "E". Errors/notes which still apply after acknowledgement are indicated alternately. During correction variable processing (temperature for correction of pH-value), the value is indicated in the same line as the error/note. Faults which are rectified of their own accord due to changed operating situations are removed from the permanent display without the need for acknowledgement.


5

Display Symbols

The display of the DULCOMETER® D1C controller uses the following symbols:

Description	Comment	Symbol
Limit value transgression Relay 1, upper	Symbol left	
Relay 1, lower	Symbol left	
Relay 2, upper	Symbol right	
Relay 2, lower	Symbol right	
Metering pump 1 (PAA) Control off	Symbol left	
Control on	Symbol left	
Metering pump 2 (De-PAA) Control off	Symbol right	
Control on	Symbol right	
Solenoid valve 1 (PAA) Control off	Symbol left	
Control on	Symbol left	
Solenoid valve 2 (De-PAA) Control off	Symbol right	
Control on	Symbol right	
Servomotor Control, open relay		 
Control, close relay		 
Without control		 
Position feedback	Thickness of bar increases from left to right during opening.	
Stop button pressed		
Manual metering		
Fault		

6 Operation




NOTE

Access to the setting menus can be barred with the access code!

The number and scope of setting menus is dependent on the device version!


If the access code is selected correctly in a setting menu, then the following setting menus are also accessible!

If within a period of 10 minutes no button is pushed, the unit automatically branches back from the calibrating menu or a setting menu to the permanent display 1.




7 Restricted Operating Menu / Overview

The restricted operating menu permits simple operation of the most important parameters. The following overview shows the settings which can be selected:




D1C2-PES-010-GB


Restricted Operating Menu / Description



Calibrating the PAA Probe

During calibration, the control function persists. The standard signal of the output (measured value) remains unchanged. The measured value registered during the start of the calibration is proposed as the PAA value; this value is adjustable (arrow keys!). Calibration is only possible if the PAA value is $\geq 2\%$ of the measuring range. On successful completion of calibration, all error checks which refer to the measured value are restarted.

**ATTENTION**
The measuring range of the probe must agree with the set measuring range (factory setting: 0–200.0 ppm). The measuring range must be reset prior to calibration (refer to page 14).




	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
	Measured value	0.1 ppm	-20 ppm	220 ppm	for measurement range up to 200 ppm
		1 ppm	-200 ppm	2200 ppm	for measurement range up to 2000 ppm

Error message	Condition	Effect
Calibration PAA not possible! Probe slope too low	PAA slope too low ($<25\%$ of norm slope)	Calibrate again
Calibration PAA not possible! Probe slope too high	PAA slope too high ($>300\%$ of norm slope)	Calibrate again
PAA value too low PAA $> x.xx$ ppm	PAA $< 2\%$ measuring range	


Restricted Operating Menu / Description

Limits



		Initial value	Possible values			Remarks
			Increment	Lower value	Upper value	
Type of limit transgression	Limit 1: Limit 2:	lower upper	upper lower off *)			Limit transgression when exceeding or dropping below value *) only with limit relays
Limit value	Limit 1:	10 ppm	0.1 ppm	-20.0 ppm	220.0 ppm	
	Limit 2:	150 ppm				
	Limit 1:	100 ppm	1 ppm	-200 ppm	2200 ppm	
	Limit 2:	1500 ppm				


Control



Restricted Operating Menu / Description

	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
Setpoint	100.0 ppm 100.0 ppm	0.1 ppm 1 ppm	-10.0 ppm -100 ppm	210.0 ppm 2100 ppm	2 setpoints necessary for control with dead zone. Setpoint 1 > setpoint 2
Control parameter xp	10 %	1 %	1 %	500 %	xp referred to measuring range
Control parameter Ti	off	1 s	1 s	9999 s	Function off = 0 s
Control parameter Td	off	1 s	1 s	2500 s	Function off = 0 s
Manual metering	0 %	1 %	-100 %	+100 %	


General Settings




	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
Alarm relay	active	active not active			
Access code	5000	1	1	9999	
Language	as per identity code	German English French Italian Dutch Spanish Portuguese Czech Japanese (as per identity code)			
Operating menu	restricted	restricted complete			

8 Complete Operating Menu / Overview

All parameters of the controller can be set in the complete operating menu (access see previous page). The following overview shows the settings which can be selected:



Complete Operating Menu / Description




Calibrating the PAA Probe (zero point and slope)

The control function is retained during the calibration procedure. The standard signal of the output (measured value) is not changed. The measured value frozen at the start of calibration is offered as the PAA value; this value is adjustable (arrow keys!). Calibration is only possible when the PAA value is ≥ 2 % of the measurement range. Once calibration has been successfully completed, all fault tracing procedures which refer to the measured value are restarted.

Zero point calibration must be carried out under real conditions in water free of PAA. Calibration is normally only necessary when measuring at the lower limit of the measuring range.

ATTENTION
The measuring range of the probe must agree with the set measuring range (factory setting: 0-200.0 ppm). The measuring range must be reset prior to calibration (refer to page 14).




	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
	Measured value	0.1 ppm	-20 ppm	220 ppm	for measurement range up to 200 ppm
		1 ppm	-200 ppm	2200 ppm	for measurement range up to 2000 ppm

Complete Operating Menu / Description

Error message	Condition	Effect
Calibration PAA not possible! Probe slope too low	PAA slope too low (<25 % of norm slope)	Calibrate again
Calibration PAA not possible! Probe slope too high	PAA slope too high (>300 % of norm slope)	Calibrate again
PAA value too low PAA > x.xx ppm	PAA <2 % of measuring range	
Zero point too low Zero point too high	< 3.7 mA > 5 mA	Check probe/cable Repeat calibration in PAA-free water


Measuring Range



	Initial value	Possible values Increment	Lower value	Upper value	Remarks
Measuring range	0...200 ppm	0...200 ppm 0...2000 ppm			

IMPORTANT
If the area allocation is changed, the PAA probe must be re-calibrated and all the menu settings must be checked!

Measured Value




IMPORTANT
If the area allocation is changed, the PAA probe must be re-calibrated and all the menu settings must be checked!

Complete Operating Menu / Description


	Initial value	Possible values		Upper value	Remarks
		Increment	Lower value		
Standard signal input lower signal limit	4 mA	0 mA 4 mA			Constant measurement signal results in message and alarm. Function off = 0 s
Allocated measured value	lower	0.00 ppm	-20.0 ppm	220.0 ppm	
		0.00 ppm	-200 ppm	2200 ppm	
	upper	200.0 ppm	-20.0 ppm	220.0 ppm	
		2000 ppm	-200 ppm	2200 ppm	
Checkout time	off	1 s	1 s	9999 s	

Correction variable*



* In the setting menu “correction value” for this equipment enables you to display the temperature or to maintain an mA signal proportional to the temperature. No temperature adjustment is made to the measured variable!



Pumps



	Initial value	Possible values		Upper value	Remarks
		Increment	Lower value		
Max. stroke/minute of pumps 1 and 2	180	1	1	500	off = 0 strokes/min


Complete Operating Menu / Description

Relay for power control



	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
Relay adjustment	as per identity code				*For "limit value", the relays remain active, even in the event of a fault. only with servomotor
Relay 1		Solenoid valve 1 Limit value 1* Actuator 1 Timer 1 Servomotor off			
Relay 2		Solenoid valve 2 Limit value 2* Actuator 2 Timer 2 off			
Period (Cycle)	10 s	1 s	10 s	9999 s	for solenoid valve for solenoid valve
min. time	1 s	1 s	1 s	Cycle/2	
Period (Cycle)	off	1 h	1 h / off	240 h	for timer for timer
t on	1 min	1 min	1 min	60 min	

Complete Operating Menu / Description



IMPORTANT


The timer will be reset if there is a drop in the power supply.

At the end of the (timer) cycle time the DULCOMETER® D1C closes the assigned relay for the duration of “t on” (timer). “Pause” interrupts the timer.

When the clock is shown in the LC display the timer can be reset to the start of the cycle at precisely this point using the enter button.

The % figure in the LC display indicates the progress of the current cycle.

Timer relays may be used, e.g. for shock metering or sensor cleaning.




The switching time of the DULCOMETER® D1C (solenoid valve) depends on the actuating variable and the “min. time” (smallest permitted operating factor of the connected device).

The actuating variable determines the ratio t_{on}/cycle and thus the switching times (see fig. above).

The “min. time” influences the switching times in two situations:


a) theoretical switching time < min. time:



The DULCOMETER® D1C does not switch for a certain number of cycles until the sum of the theoretical switching times exceeds the “min. time”. Then the DULCOMETER® D1C switches for the duration of this total time.


Complete Operating Menu / Description

b) theoretical switching time > (cycle - min. time) and calculated switching time < cycle



The DULCOMETER® D1C does not deactivate for a certain number of cycles until the differences between cycle and theoretical switching time exceed the “min. time”.

Limit values



	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
Type of limit transgression					
Limit 1:	lower	upper			Limit transgression when exceeding or dropping below value *) only with limit relay
Limit 2:	upper	lower			
Limit value	Limit 1: 10.0 ppm Limit 2: 150.0 ppm	0.1 ppm	-20.0 ppm	220.0 ppm	
Limit value	Limit 1: 100 ppm Limit 2: 1500 ppm	1 ppm	-200 ppm	2200 ppm	
Hysteresis limits	4.0 ppm 40 ppm	0.1 ppm 1 ppm	0 ppm 0 ppm	220.0 ppm 2200 ppm	Effective in direction of “Cancelling limit transgression”
Checkout time limits Δt on	off	1 s	1 s	9999 s	Results in message and alarm. off = 0 s: Function switched off, no message, no alarm
Control	on	on off			

Complete Operating Menu / Description

	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
Switching direction Limit value 1; Limit value 2	active closed	active closed active open			Acts as N/O Acts as N/C
Switch-on delay Δt on	0 s	1 s	0 s	9999 s	
Switch-off delay Δt off	0 s	1 s	0 s	9999 s	

If the limit is exceeded for longer than the “Delay time - limit values” an error message is given, which must be acknowledged, and the alarm relay circuit is broken. If “Controller” is also set to “off” the control process stops.


Servomotor

The **operating range** is defined by the total resistance range of the feedback potentiometer. The maximum limit of the range actually used is set by defining the **control range**.



CAUTION

- **Activation of the servomotor must be carried out with the same meticulous care as taken when calibrating a measuring probe.**
- **To ensure correct operation, the activation time of the actuator used should not be less than 25 seconds for the control range from 0...100 %!**




Complete Operating Menu / Description

	Initial value	Possible values		Lower value	Upper value	Remarks
		Increment				
Servomotor	setting	setting ok off				
Control direction	PAA	PAA De-PAA				
Control range	100 %	1 %	10 %	100 %		in % of operating range

NOTE

- When the wide bar is as far right as it will go the stroke adjustment motor is fully open.
- The permanent display shows to what degree the motor has opened in % (the greater the percentage, the farther open the stroke adjustment motor).

Control



	Initial value	Possible values		Lower value	Upper value	Remarks
		Increment				
Control	normal	normal with dead zone manual				When controlling with dead zone, the regulated value is not used for measured values within the dead zone.

Complete Operating Menu / Description

	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
Setpoint setting	100.0 ppm 1000 ppm	0.1 ppm 1 ppm	lower measure- ment threshold	upper measure- ment threshold	2 setpoints necessary for control with dead zone. Setpoint 2 ≥ Setpoint 1
Control parameter xp	10 %	1 %	1 %	500 %	xp referred to measuring range
Control parameter Ti	off	1 s	1 s	9999 s	Function off = 0 s
Control parameter Td	off	1 s	1 s	2500 s	Function off = 0 s
Additional basic load	0 %	1 %	-100 %	+100 %	
Manual metering	0 %	1 %	-100 %	+100 %	


Abbreviations for control variables:

x_p: 100 %/K_p (inverse proportional coefficient)

T_i: Integration time of I-controller [s]

T_d: Differential time of D-controller [s]


Feed forward control




	Initial value	Possible values			Remarks
		Increment	Lower value	Upper value	
Feed forward control (Flow)	as per identity code	None 10 Hz 500 Hz			Signal processing: Signal <0.02 Hz = No flow Signal <0.2 Hz = No flow Signal <0.2 mA = No flow Signal <4.2 mA = No flow
Feed forward control rated value	at standard signal: 4–20 mA	0...20 mA 4...20 mA			
	10 Hz	0.01 Hz	0.1 Hz	10 Hz	
	500 Hz	1 Hz	1 Hz	500 Hz	
	20 mA	0.1 mA	0/4 mA	20 mA	
Feed forward control effect	multiplicative	multiplicative additive			Depended on signal type. Maximum limitation of range used.
Max. add. regulated value	100 %	1 %	-500 %	+500 %	only with add. feed forward control

Complete Operating Menu / Description

Standard Signal Output 1




Standard Signal Output 2



	Initial value	Possible values Increment	Lower value	Upper value	Remarks
Variable allocation	as per identity code	Measured value Controlled variable Correction value			If control is present only with correction variable
Output range	0...20 mA	0...20 mA 4...20 mA			
Range measured value	0...200.0 ppm 0...2000 ppm	0.1 ppm 1 ppm	-20.0 ppm -200 ppm	220.0 ppm 2200 ppm	Minimum range 1 %
Range controlled variable	-100 %...0 %	1 %	-100 %	+100 %	Minimum range 1 %
Range correction value	0...100 °C	0.1 °C	0 °C	100 °C	Minimum range 1 °C

Complete Operating Menu / Description

General setting



	Initial value	Possible values		Lower value	Upper value	Remarks
		Increment				
Alarm relay	active	active not active				acts as N/O acts as N/C Alarm relay can be activated by pause contact.
Pause	normal	normal hold				
Control input pause	active closed	active closed active open				
Pause alarm	alarm off	alarm off alarm on				
td	0 min	1 min	0 min	60 min		
Access code	5000	1	1	9999		
Language	as per identity code	German English French Italian Dutch Spanish Portuguese Czech Japanese (as per identity code)				
Operating menu	complete	restricted complete				

Complete Operating Menu / Description

Standard Pause

If the pause-switch is off, the DULCOMETER® D1C sets the operating outputs to “0” for as long as the pause-switch is off or for a set time-delay t_d (if t_d is set to > 0 min). Whilst the pause-switch is off, the D1C establishes the P-proportion in the background.

With PID-control (Identity code characteristics “control characteristic” = 2): the I-proportion is stored when the pause is switched off (I-proportion then usually only present if $T_i > 0$ has been selected in the “Control setting?” setting menu).

Exception: the standard signal outputs mA for the measured value or correction value are not affected by the pause.

After pause is activated the operating outputs remain at “0” for the length of the time-delay t_d . The time-delay t_d must be set up in such a way that, in this time e.g. sample water (process-specific current concentration) flows to the sensor.

With PID-control (Identity code characteristics “control characteristic” = 2): The control variable output resulting from the pause and the expiry of the time-delay t_d is reconciled jointly with the current P-component and (if T_i is set > 0) with the stored I-component.

Pause Hold

If the pause-switch is off, the DULCOMETER® D1C freezes the operating output at the most recent value for as long as the pause-switch is off or for a set time-delay t_d (if t_d is set to > 0 min). Whilst the pause-switch is off, the D1C establishes the P-proportion in the background.

With PID-control (Identity code characteristics “control characteristic” = 2):

Even the mA standard signal outputs for measured value or correction value are frozen.

After pause is activated the operating outputs remain frozen for the length of the time delay t_d . The time delay t_d must be set up in such a way that, in this time e.g. sample water (process-specific current concentration) flows to the sensor.

With PID-control (Identity code characteristics “control characteristic” = 2): The control variable output resulting from the pause and the expiry of the time-delay t_d is reconciled jointly with the current P-proportion and (if T_i is set > 0) with the newly established I-proportion.

EC Declaration of Conformity

We,

ProMinent Dosiertechnik GmbH
Im Schuhmachergewann 5 - 11
D - 69123 Heidelberg

hereby declare that, on the basis of its functional concept and design and in the version brought into circulation by us, the product specified in the following complies with the relevant, fundamental safety and health stipulations laid down by EC directives.

Any modification to the product not approved by us will invalidate this declaration.

Product description : ***Measurement and control system, DULCOMETER***

Product type : ***D1C / D2C***

Serial number : ***see type identification plate on device***


Relevant EC regulations : ***EC - low voltage directive (73/23/EEC)***
EC - EMC - directive 89/336/EEC subsequently 92/31/EEC

Harmonized standards used,
in particular : ***EN 60335-1, EN 61010-1/2, EN 60204-1***
EN 50081-1/2, 50082-1, EN 55014-1/2
EN 61000-3-2/3, EN 61000-6-2

National standards and other
technical specifications used,
in particular :

Date/manufacturer's signature :

11th December 2000



The undersigned :

Dr. Rainer V. Dulger, Executive Vice President R&D and Production

10 Fault / Remarks / Troubleshooting

Fault	Fault text	Symbol	Effect on metering	Effect on control	Alarm with ack- nowledgement	Remarks	Remedy
Measured value Checkout time measured value exceeded	<i>Check P44 probe</i>	☹	Basic load	Stop	Yes	Function defeatable	Check function of probe
Signal exceeded/drops below value	<i>P44 input < 3 mA P44 input > 23 mA</i>	☹	Basic load	Stop	Yes	Signal <3.0 ±0.2 mA or >23 ±0.2 mA	Check probe, transducer and cable connection
Calibration probe with error	<i>P44 calibr. defective</i>	☹	Basic load	Stop	No	Metering continues in case of error with un- steady measured values	Check probe, replace if necessary, recalibrate if necessary
Correction variable Signal exceeded/drops below value	<i>temp. input ↑ temp. input ↓</i>	☹			yes	PT100-signal > 138.5 Ω Signal <3.0 ±0.2 mA or >23 ±0.2 mA Value last valid is used	Check probe, transducer and cable connection
Feed forward control Signal drops below value multiplicative additive Signal exceeded	<i>feedfwd. < 4 mA feedfwd. > 23 mA</i>	☹ ☹	Stop		Yes Yes	Signal <4.0 ±0.2 mA or >23 ±0.2 mA Value last valid is used	Check probe, transducer and cable connection
Limit transgression after checkout time limit value	<i>P44 limit 1 P44 limit 2</i>	☹			Yes	Function defeatable	Define cause, reset values if necessary
Servomotor Position not reached	<i>Servomotor defective</i>	☹			Yes	Servomotor closes	Check servomotor
Electronics error	<i>System error</i>	☹ ☹	Stop	Stop	Yes	Elektronik data defective	Call in service

Operation	Note text	Symbol	Effect on metering	Effect on control	Alarm with acknowledgement	Remarks	Remedy
Pause contact	Pause	EO	Stop	Stop	No/Yes	No further fault check	-
	Pause/Hold	E		PI-part frozen			
Stop button	Stop	EO	Stop	Stop	No	Relay drops out	-
During calibration probe			Basic load + Feed forward control	Stop in complete operating menu	No	No error processing of measured variable	-
Probe slope too low	Slope low	E	Basic load	Stop	No	25% > probe of slope > 300% norm slope	Check probe, replace if necessary
Probe slope too high	Slope high						
PAA-value <2 % measuring range	PAA too low					< 2 % from meas. range	
Zero point	Zero point low Zero point high	E	Basic load	Stop	No	Signal < 3 mA Signal > 5 mA	Check probe/cable Repeat calibration in PAA-free water
During servomotor setting	Position feed back wrong Upper position <40 % max. value Lower position >30 % range					Without correct adjustment the last valid values are still used	Check connection of relay, potentiometer Adjust the operation region of the servomotor correctly

